

# IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

## READ ALL INSTRUCTIONS BEFORE USING THIS MIRROR

## KEEP AWAY FROM WATER

**DANGER** — TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS MIRROR FROM THE ELECTRICAL OUTLET BEFORE CLEANING.

**WARNING** — TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. This mirror should not be used by or near children or individuals with certain disabilities.
3. Use this mirror only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this mirror if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the mirror to a service centre for examination and repair.

5. Keep the cord away from heated surfaces.
6. Never operate the furnishing with the air openings blocked, keep the air openings free of lint, hair, and the like.
7. Never drop or insert an object into any opening.
8. Do not use outdoors.
9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
10. To disconnect, touch mirror base until light shuts off, then remove plug from outlet.
11. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
12. Do not use on a soft surface such as a bed, where openings may be blocked.
13. Touch mirror base until light shuts off, allow unit to cool and unplug cord before replacing light bulbs.
14. Do not place or store mirror where it can fall or be pulled into a tub or sink.
15. If mirror falls into water, unplug it immediately. Do not reach into the water.
16. Never use while sleeping.
17. Do not use bulb greater than 30 watts. Use in any 120 volt, 60 hertz AC electrical outlet (ordinary house current). Do not use in any other electrical outlet.
18. To protect against electrical hazards, do not use while bathing or in the shower.
19. Unplug the mirror from outlet before cleaning. Do not leave mirror unattended when it is plugged in.

## FOR HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

## OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this product has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

1. Your lighted makeup mirror features a 1x and 7x magnification for the 8.5 in. mirror head.
2. Your lighted makeup mirror will adjust to many different angles. Simply tilt the neck or head backward or forward to adjust to the desired angle. Your mirror will also swivel so that you can use either the normal view or the magnified view located on the opposite side.
3. Plug into any standard 120 volt wall outlet. The mirror light is activated by touch. Touch the base to control the light settings. The first touch will turn the light on to the low setting. A second and third touch changes light settings to medium and high. A fourth touch will turn off the mirror light.
4. After use, always touch the base to turn the mirror to the OFF position and unplug.

## TO REPLACE BULB

**CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB.**

**NOTE:** Do not use a bulb greater than 30 watts. Contact the Conair service center at 1-800-472-7606 for replacement bulb information. (Ask for replacement bulb RP111.)

1. Unscrew screws from opposite sides of the mirror housing near the rotating hinges (Fig. 1).
2. Carefully lift off the top half of the housing from the bottom half that is affixed to the arm.
3. Unscrew the old bulb and replace with the new bulb (Fig. 2).
4. Carefully replace the top housing half after locating and aligning the screw holes to the bottom half. If the holes don't line up, turn top half of mirror 180°.
5. Insert two screws back into screw holes and tighten with screw driver. Do not over-tighten.




Figure 1




Figure 2

**CAUTION:**  
TO PREVENT ELECTRIC SHOCK, MATCH WIDE  
BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

**CAUTION:**  
**RISK OF FIRE, USE ONLY  
30 WATTS MAXIMUM 120  
VOLT; TYPE T BULBS.**

**DISCONNECTED FROM THE  
SUPPLY CIRCUIT BEFORE  
SERVICING OR CLEANING.**

**DO NOT SUBMERSE.**

**MODEL: TGBE87CRC  
RATING: 120V AC 60Hz 30W  
DATE CODE:**

## MAINTENANCE


Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed. If cleaning becomes necessary, disconnect the appliance from the power source, allow to cool, and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. To protect against electrical hazards, do not light until you are certain mirror is completely dry. If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair. Handle cord carefully to prolong its life; do not jerk or strain at plug connections or wrap cord around mirror for storage. This could cause damage to the cord and the mirror could short circuit. To store mirror, coil cord loosely.

## STORAGE

Disconnect from electrical outlet. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where it will not be damaged.

**WARNING:  
IF YOU THINK THE  
POWER IS OFF  
WHEN THE SWITCH  
IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically alive even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

## LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below that is nearest you, together with your purchase receipt and \$7.50 for postage and handling. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.**

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.**

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

## SERVICE CENTRE

©2014 CONAIR CONSUMER PRODUCTS ULC  
100 Conair Parkway  
Woodbridge Ontario, L4H 0L2  
For more information on any Conair product call: 1-800-472-7606  
Visit our Web site:  
[www.conaircanada.ca](http://www.conaircanada.ca)  
Consumer Call Centre E-mail:  
[Consumer\\_Canada@Conair.com](mailto:Consumer_Canada@Conair.com)

13CN146037

renew · refresh · revive

true glow™

Soft halo lighting for a gentle glow.



**1x/7x**  
Magnification

Fog-free Viewing

Elegant Polished  
Chrome Finish

Touch Control Lighting  
8.5 inch (22 cm) Diameter  
Double-Sided Viewing

## Have a Question?

*Please do not return this product  
to the retailer.*

**Call Us First!**

**Our customer service and product  
experts are ready to answer ALL your  
questions.**

**Please call our TOLL-FREE customer  
service number at: 1-800-472-7606  
or visit us online at  
[www.conaircanada.ca](http://www.conaircanada.ca)**

**CONAIR®**

Model TGBE87CRC

IB- 12601